


DIMENSIONS (mm/in)



WIRING & ADJUSTMENT

The transmitter is factory calibrated for the required range within the specified accuracy, prior to delivery. Any further calibration should normally not be necessary. The sensor and the electronic unit are calibrated together. If either of these are replaced, the transmitter is no longer in calibration.

The built in amplifier is equipped with two trim potentiometers:

- ZERO to adjust the lower end of the range, 4 mA.
- SPAN to adjust the upper end of the range, 20 mA.

When calibrating, adjust ZERO first and then SPAN. Because of a certain degree of interaction, the adjustment process must be repeated several times.

