» RDF-IR

Ceiling sensor surface temperature

Datasheet

Subject to technical alteration Issue date: 16.10.2019 • A101





Illustration similar

hermoka

HOME OF SENSOR TECHNOLOGY

» APPLICATION

Ceiling flush-mounted sensor for surface temperature measurement in room, office spaces and other workplaces. Using the infrared measuring principle, an averaged temperature over the circular detection range (optical detection range 80 ±5°) is performed. If two IR sensors are used, the mean, minimum or maximum value of both temperature signals can be provided in addition to the individual temperatures of each sensor (configurable via Thermokon USEapp).

» TYPES AVAILABLE

Ceiling flush mount sensor temperature – active 0..10 V | 4..20mA RDF-IR V L1500 RDF-IR A L1500

Ceiling flush mount sensor temperature – active 2x 0..10 V | 2x 4..20 mA RDF-IR VV L1500 RDF-IR AA L1500

Ceiling flush mount sensor temperature – active 2x 0..10 V + Relay RDF-IR VV L1500 Relay

» SECURITY ADVICE – CAUTION



The installation and assembly of electrical equipment should only be performed by authorized personnel.

The product should only be used for the intended application. Unauthorised modifications are prohibited! The product must not be used in relation with any equipment that in case of a failure may threaten, directly or indirectly, human health or life or result in danger to human beings, animals or assets. Ensure all power is disconnected before installing. Do not connect to live/operating equipment.

Please comply with

- Local laws, health & safety regulations, technical standards and regulations
- Condition of the device at the time of installation, to ensure safe installation
- This data sheet and installation manual

»NOTES ON DISPOSAL



As a component of a large-scale fixed installation, Thermokon products are intended to be used permanently as part of a building or a structure at a pre-defined and dedicated location, hence the Waste Electrical and Electronic Act (WEEE) is not applicable. However, most of the products may contain valuable materials that should be recycled and not disposed of as domestic waste. Please note the relevant regulations for local disposal.

» PRODUCT TESTING AND CERTIFICATION

C Declaration of conformity

The declaration of conformity of the products can be found on our website https://www.thermokon.de/.

» TECHNICAL DATA

Measuring values	surface temperature		
Output voltage	1x/2x 010 V or 05 V (adjustable via jumper; live-zero configuration via Thermokon USEapp), min. load 10 $k\Omega$		
Output ampere (type-dependent)	A AA 1x/2x 420 mA, max. load 500 Ω		
Output switch contact (type-dependent)	Relay 2x floating contact NO for 24 V ~ or 24 V = / 3 A		
Power supply (type-dependent)	V VV Relay 1535 V = or 1929 V ~ SELV	A AA 1535 V = SELV	
Power consumption	typ. 0,6 W (24 V =) 1,5 VA (24 V ~)		
Output signal range temperature *Scaling analogue output	0+50 °C (default setting) selectable from 4 temperature ranges -40+60 °C 0+50 °C -20+80 °C -15+35 °C adjustable at the transducer		
Operating temperature range * Max. permissible operating temperature	-20+70 °C		
Accuracy Temperature	\pm 0,5 K (typ.at 21 °C within default measuring range) mounting height max. 7 m, > 7m \pm 1,5 K		
Sensor	PIR (passive infrared), optical aperture angle (50% sensitivity): 80 \pm 5° Emissivity = 1.0, other values on request		
Enclosure	enclosure USE-M, PC, pure white		
Protection	IP30 according to EN 60529		
Cable entry (type-dependent)	V(V) A(A) Flextherm M20, for wire Ø=4,59 mm, removable	Relay M25 with fourfold cable entry for wire with max. Ø=7 mm, removable	
Connection electrical	removable plug-in terminal, max. 2,5 mm², sensor wire length=1,5 m (default), max. 10 m, plug RJ45		
Ambient condition	max. 85% rH short term condensation		

» CONFIGURATION



The Thermokon bluetooth dongle with micro-USB is required for communication between USEapp and USE-M / USE L (Item No.: 668262). Commercial bluetooth dongles are not compatible.

Application-specific reconfiguration of the devices can be performed using the Thermokon USEapp. The configuration can be performed only when the device is powered

The configuration-app and the app description can be found in the Google Play Store or in the Apple App Store.

» APPLICATION NOTICE




The housing cover must be completely closed in order to ensure the accuracy and reproducibility of the measured values during a test or service log via USEapp.


The Bluetooth dongle snaps into the socket easily. When removing, please fix the plug-in card (option PCB) so that it is not unintentionally pulled out.

The ceiling flush mounted sensor is installed in a 26 mm diameter hole.

» APPLICATION





» CONNECTION PLAN



(temperature 2 | 0..10 V) optional, if sensor 2 connected (temperature 1 | 0..10 V) (15..35 V = or 19..29 V ~)

RDF-IR A | RDF-IR Dual AA






(temperature 2 | 0..10 V) optional, if sensor 2 connected (temperature 1 | 0..10 V) (15..35 V =)

(temperature 2 | 4..20 mA) optional, if sensor 2 connected (temperature 1 | 4..20 mA)

RDF-IR V Relay | RDF-IR Dual VV Relay




(temperature 2 | 0..10 V) optional, if sensor 2 connected (temperature 1 | 0..10 V) (15..35 V = or 19..29 V ~)

(Relay 2 | NO) (Relay 1 | NO)

» DIP SWITCH CONFIGURATION

DIP 13	#0 reserved			
Measuring range - DIP 4,5				
ON 1 2 3 4 5 6	#0 (factory default) SI = 0+50 °C IMP = +40+140 °F	ON 1 2 3 4 5 6	#8 SI = -20+80 °C IMP = 0+200 °F	
ON 1 2 3 4 5 6	#16 SI = -40+60 °C IMP = -40+160 °F	ON 1 2 3 4 5 6	#24 SI = -15+35 °C IMP = 0+100 °F	
System of units - DIP 6				
ON 1 2 3 4 5 6	#0 (factory default) SI	ON 1 2 3 4 5 6	#32 IMP	

» DIMENSIONS (MM)



» ACCESSORIES (INCLUDED IN DELIVERY)

Mounting base Mounting kit universal

Cover screw + screw cover• 2 Rawlplugs • 2 Screws (countersunk head) • 2 Screws (rounded head)

» ACCESSORIES (OPTIONAL)

Bluetooth dongle Cable entry M25 USE white, sealing insert 4x Ø=7 mm (4 pcs) Item No. 631228 Item No. 698511

Item No. 668262 Item No. 641364